SHARP

MICRO COMPONENT SYSTEM

MODEL

XL-MP10H

OPERATION MANUAL

COMPACT disc DIGITAL AUDIO

SAVING ENERGY STAND-BY POWER CONSUMPTION 0.9W

MP3

Thank you for purchasing this SHARP produ
To obtain the best performance from this p
manual carefully. It will guide you in operati

XL-MP10H Micro Component System consistin
and CP-S10H (speaker system).



Accessories

Please confirm that the following accessories a

 **Remote control × 1**	 **"AA" size battery (UM/SUM-3, R6, HP- or similar) × 2**

Note:
Only the above accessories are included.

Special notes

Warning:

- When the ON/STAND-BY button is set at STAND-BY position, mains voltage is still present inside the unit. When the ON/STAND-BY button is set at STAND-BY position, the unit may be brought into operation by the timer mode or remote control.
- This unit contains no user serviceable parts. Never remove covers unless qualified to do so. This unit contains dangerous voltages, always remove mains plug from the socket before any service operation and when not in use for a long period.
- To prevent fire or shock hazard, do not expose this appliance to dripping or splashing. No objects filled with liquids, such as vases, should be placed on the apparatus.

CAUTION

- This product is classified as a CLASS 1 LASER product.
- Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

  As the laser beam used in this compact disc player is harmful to the eyes, do not attempt to disassemble the cabinet. Refer servicing to qualified personnel only.

Laser Diode Properties
Material: GaAlAs
Wavelength: 780 nm
Emission Duration: continuous
Laser Output: max. 0.6 mW


CAUTION-INVISIBLE LASER RADIATION WHEN OPEN.
DO NOT STARE INTO BEAM OR VIEW DIRECTLY WITH
OPTICAL INSTRUMENTS.
WARNUNG-UNSICHTBARE LASERSTRAHLUNG WENN GERÄT
GEÖFFNET. NICHT IN DIE STRAHLUNG SCHAUEN ODER
DIREKT MIT OPTISCHEN HILFSMITTELN BETRACHTEN.
ATTENTION-RAYON LASER INVISIBLE EN CAS D'OUVERTURE.
NE PAS REGARDER LE FAISCEAU DIRECTEMENT OU AVEC DES
INSTRUMENTS OPTIQUES.

Note for users in Australia:
Copyright may exist in material you wish to record. Copying or broadcasting such material without permission of the relevant licensees or owners of the copyright is prohibited by law. SHARP is not in a position to authorise the copying or broadcasting of copyright materials and nothing in this OPERATION MANUAL should be implied as giving that authority.

For other countries:
Audio-visual material may consist of copyrighted works which must not be recorded without the authority of the owner of the copyright. Please refer to the relevant laws in your country.

Contents

■ General Information
Precautions . . . . . .
Controls and indicators . . . . . .

■ Preparation for Use
System connections . . . . . .
Remote control . . . . . .

■ Basic Operation
Sound control . . . . . .
Setting the clock . . . . . .

■ Disc Playback
Listening to a disc . . . . . .
Advanced disc playback . . . . . .

■ Radio
Listening to the radio . . . . . .
Listening to the memorised station . . . . .

■ Tape Playback
Listening to a cassette tape . . . . . .

■ Tape Recording
Recording on a cassette tape . . . . . .

■ Advanced Features
Timer and sleep operation . . . . . .

■ References
Troubleshooting chart . . . . . .
Maintenance . . . . . .
Specifications . . . . . .

WARRANTY . . . . . .

Precautions

■ General

- Please ensure that the equipment is positioned in a well ventilated area and that there is at least 10 cm of free space along the sides and back. There must also be a minimum of 20 cm of free space on the top of the unit.



- Use the unit on a firm, level surface free from vibration.

- Keep the unit away from direct sunlight, strong magnetic fields, excessive dust, humidity and electronic/electrical equipment (home computers, facsimiles, etc.) which generate electrical noise.

- Do not place anything on top of the unit.
- Do not expose the unit to moisture, to temperatures higher than 60°C or to extremely low temperatures.
- If your system does not work properly, disconnect the AC power lead from the wall socket. Plug the AC power lead back in, and then turn on your system.
- In case of an electrical storm, unplug the unit for safety.



- Hold the AC power plug by the head when removing it from the wall socket, as pulling the lead can damage internal wires.
- **Do not remove the outer cover, as this may result in electric shock. Refer internal service to your local SHARP service facility.**
- The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, tablecloths, curtains, etc.
- No naked flame sources, such as lighted ca placed on the apparatus.
- Attention should be drawn to the environment tery disposal.
- This unit should only be used within the range o

Warnings:

- The voltage used must be the same as that spe Using this product with a higher voltage other specified is dangerous and may result in a fir accident causing damage. SHARP will not be for any damage resulting from use of this unit w than that which is specified.
- **CD players use a laser pickup which can da viewed directly. Do not look at the pickup, a the pickup directly.**

■ Volume control

The sound level at a given volume setting depend ciency, location, and various other factors. It is a exposure to high volume levels. Do not turn the v switch on and listen to music at moderate levels.

Preview Limit Reached! To view more of this manual, please visit:
http://freemanualdownload.com/Sharp-MICRO-COMPONENT-SYSTEM-CPS10H-free-manual-download